

HOW TO INSTALL 1" IR FILTERS

If you have purchased a 1" circle, infrared filter, we found a very easy way to install these filters as followed.

What you need:

- 1" IR Circle filter from <http://www.WhitetailSupply.com>
- 3/8" thick self stick EVA foam for 1020 cases
- 5/16" thick self stick EVA foam for 1040 cases
- A precision exacta knife or 1" circle slicer

If you order a flash gasket from us, the 1" holes are precision cut from a laser circle.

Once the **1" Flash Hole** is cut or drilled, in your foam, we just simply push the 1" IR filter into place as shown in picture 2.



Picture 2 shows the perfect tight fit of the 1" IR circle filter installed.



The great benefit of doing it this way is that you can just *pluck* the IR filter out of the foam at any time, if you want to use the camera case as a white flash unit instead of infrared.

Also this method does not require any messy goop 😊

Whitetail Supply & Feed, LLC
All rights reserved, reference use only
8-1-06