

---

## MALE BRACKET MODIFICATION

**Modification at your own liability-**The male bracket that you attach to your camera case or video unit, can be further modified for a more professional look-feel and waterproofing!

Tools we used: Bench-top Belt Sander

If you take a look at the 1<sup>st</sup> picture below, you can see the ridge on the left & right side. Once we remove these (2) sidewall ridges we can obtain a smooth surface from the belt sander and acquire a much easier & yet flush mount install with stronger adhesion by applying GOOP to the backside of the male bracket before applying.

1. Sand the 2 ridges from the back wall of the Male Bracket
2. Locate the area you will mount the bracket to i.e. Backside of your trail camera case- be sure nothing is on the opposite side of the object, you are going to drill out for the (2) mounting holes.
3. Next be sure bracket is relatively straight & use a pencil to outline it
4. Next we use a 9/64" drill bit and drill out the (2) mounting holes
5. Next lift the bracket up and apply a layer of GOOP to the backside
6. Apply the bracket onto the outlined area and install the 2 screws or the rivet method of your choice.

